


# Drop in anchor SETTING TOOL

## Description

Setting tool DI-TOOL guarantees a controlled expansion and setting of Drop in anchors.



Item code	Size	Qty Per Box	Qty Per outer	Weight Per 100
	Ø			
	mm			kg
<b>DI-TOOL-6</b>	M6	1	200	6
<b>DI-TOOL-8</b>	M8	1	200	6
<b>DI-TOOL-10</b>	M10	1	100	10
<b>DI-TOOL-12</b>	M12	1	100	19
<b>DI-TOOL-16</b>	M16	1	50	36
<b>DI-TOOL-20</b>	M20	1	50	45

## Installation instructions

