Setting tool for Hollow Wall Anchors M4 to M6

Description

The leader of the range: efficient and convenient!


Fitted with a reset trigger. - the MD setting tool offers easy and flawless installation.

Features

- Suitable for hollow wall anchors M4 to M6.


Technical details

Material body and mobile handle: Steel Weight: 0.36 Kg





Setting instructions



- 1. Pierce the support to the correct specified diameter.
- 2. Enter the anchor flush with hole. Unscrew anchor by ± -4 mm.
- 3. Position the nose of the expansion clamp between the collar of the anchor and the screw head.
- 4. Operate the pliers to expand the anchor.
- 5. Remove the screw to position the object to be fixed. Screw the assembly in by using a screwdriver.



Construction Fixings ■ **Rivets & Rivet nuts**

Setting Tools

Tel: 01785 246539 Email: sales@sellit.co.uk www.scellit.co.uk