


# CORDLESS RIVET TOOL

FOR TRIFORM RIVET Ø5.2 to Ø7.8 mm

# ELEMENT T



## SPECIFICATIONS

**Traction power:**  
12 000 N (2.640 lbs min.)

**Stroke:**  
25 mm (0.827")

**Setting speed:**  
Around 20 cycles per minute

**Weight (incl. battery):**  
2.15 kg (4.73 lbs)

**Battery:**  
18 V Li-ion - 2.0 Ah with charger indicator.

**Charger:**  
18V - battery charging time 2.0 Ah = 100 % in 30 minutes

**Warranty:**  
1 year

## CAPACITY

Blind rivet Ø5,2 to Ø7,7 mm, all materials.



RIVETS	Ø5.2	Ø6.4	Ø7.8
ALUMINIUM	✓	✓	✓
STEEL	✓	✓	✓
STAINLESS STEEL	✓	✓	✓

## FEATURES



3 LEDS TO ILLUMINATE THE WORK ZONE



BATTERY WITH CHARGE INDICATOR



SMOOTH TRIGGER AND GRIP



UPSIDE-DOWN STAND

## REFERENCES

REFERENCE	COMPOSITION			
	RIVETING E-T	BATTERY 18V Li-Ion -2.0Ah	QUICK CHARGER 18V	ACCESSORIES
E-T-2XBAT	1	2	1	1
E-BATT		1		
E-CHARG			1	


### Accessories included:

- 3 nosepieces Ø5,2 - Ø6,4 - Ø7,7mm for triform rivet.
- 1 belt hook.
- 1 mounting wrench.
- 1 additional jaws set.
- 1 rigid carrying case.



rigid carrying case

# OPERATING INSTRUCTIONS



- 1 Trigger
- 2 Nosepiece
- 3 Mandrel container
- 4 Belt hook
- 5 Battery
- 6 Lock / unlock battery
- 7 LED lights

## • RIVETING:

1 - Choose the nosepiece according to the diameter of the rivet to set. Please refer to the adjacent table to find the right nosepiece.

**CAUTION**  
the use of the wrong nosepiece can damage the tool.

- 2 - Place the rivet mandrel into the nosepiece.
- 3 - Place the rivet body in the hole of the assembling part.
- 4 - Operate the trigger until the rivet mandrel breaks.

NOSEPIECES	
Nosepiece	Rivet Ø (mm)
A	Ø5.2
B	Ø6.4
C	Ø7.8

## • REPLACING NOSEPIECE:

Nosepieces 2 are marked with figures A-B-C linked with rivet diameters. Use the SW13 key to replace the nosepiece. See user manual for more details.

## • REMOVE THE BATTERY:

Battery 5 is locked to the riveting tool with a spring. To remove the battery, press the 2 unlock buttons 6 and slide the battery.

## • BATTERY LEVEL INDICATOR:

4 lights on the battery panel allows you to check the remaining power. Press and hold the blue button to check the battery level :

- 4 lights on : 100% remaining
- 3 lights on : 75% remaining
- 2 lights on : 50% remaining
- 1 light on : 25% remaining

The information on the battery panel can vary (+/- 5%) due to environmental conditions.



## • LED LIGHTS:


The tool is equipped with 3 powerful LED lights to enlight the work place.

### Turn on the light only


Press the trigger half way to turn on the light. The lights will shutdown after 10'.

### Turn on the tool with the lights on

Press the trigger to set the rivet. The lights turn on and remain on until 10' after the trigger is released.



Red light on the charger: the battery has to be charged



Green light on the charger: the battery is fully charged

# MAINTENANCE / TROUBLESHOOTING / SAFETY INFORMATION

See user manual.